

# Allowing Free Charging

Version 2



# Allowing Free Charging – Version 2

## Step 1

After logging into the controller select AUTHORIZATION.  
Click on the drop-down menu to select ON or OFF.

OFF = A charge session will need RFID access or access via the back-office app.

ON = This is a plug an play charging session.

The screenshot shows the GARO Configuration Interface in a web browser. The browser address bar shows the URL `192.168.123.123/groups/authorization`. The page title is "Configuration Interface". The GARO logo is visible in the top left corner. The page content is organized into sections:

- Free Charging**
  - Free Charging: Off
  - If in doubt allow charging: Off
- General**
  - Vehicle connection timeout: 180
  - Send Authorize for RemoteStart: On
  - Stop Transaction Mode: Normal
  - Lock Actuator only if authorized: Off
- RFID Settings**
  - RFID Tag letter case: Lower Case
  - Enforce Master RFID: Off
  - Enforce using Secure RFID: Off
  - Language of Display: Multi-Language EN-DE-FR-NL

The left sidebar contains a navigation menu with the following items: DASHBOARD, NETWORK, BACKEND, AUTHORIZATION (selected), Free Charging, General, RFID Settings, RFID Whitelists, WHITELISTS, LOAD MANAGEMENT, INSTALLATION, and SYSTEM.



**UNITED KINGDOM**  
**PHONE NUMBER: +44 (0) 121 3899 444**  
**EMAIL: TECHNICAL@GARO.CO.UK**

**IRELAND**  
**PHONE NUMBER: +353 (0) 1 866 5360**  
**EMAIL: EV@GARO.IE**



<https://www.garoelectric.com/marketing-hub>